

# Control unit IndraDrive

## Commissioning

### Linear axis LDx with IndraDrive control unit



**Imprint:****Copyright:**

This manual remains the copyrighted property of SCHUNK GmbH & Co. KG. It is solely supplied to our customers and operators of our products and forms part of the unit. This documentation may not be duplicated or made accessible to third parties, in particular competitive companies, without our prior permission.

**Technical changes:**

We reserve the right to make alterations for the purpose of technical improvement.

**Edition:** 01.03/ 21.09.2012 / en

© SCHUNK GmbH & Co. KG, Lauffen/Neckar

All rights reserved

Dear Customer,

Congratulations on choosing a SCHUNK product. By choosing SCHUNK, you have opted for the highest precision, top quality and best service.

**You are going to increase the process reliability of your production and achieve best machining results – to the customer's complete satisfaction.**

**SCHUNK products are inspiring.**

Our detailed assembly and operation manual will support you.

Do you have further questions? You may contact us at any time – even after purchase. You can reach us directly at the mentioned addresses in the last chapter of these instructions.

Kindest Regards,

Yours SCHUNK GmbH & Co. KG

Precision Workholding Systems

Bahnhofstr. 106 – 134

D-74348 Lauffen/Neckar

Tel. +49-7133-103-2503

Fax +49-7133-103-2189

automation@de.schunk.com

www.schunk.com



## Table of contents

<b>1</b>	<b>About this manual.....</b>	<b>4</b>
1.1	Purpose/validity .....	4
1.2	Applicable documents (on CD-ROM) .....	4
1.3	Symbole in dieser Anleitung.....	4
<b>2</b>	<b>Basic safety notes .....</b>	<b>5</b>
2.1	Intended use .....	5
2.2	Environmental and operating conditions .....	5
2.3	Controlled production .....	5
2.3.1	Protective equipment.....	5
2.3.2	Constructional changes, attachments, or modifications.....	6
2.4	Personnel qualification .....	6
2.5	Safety-conscious working.....	6
<b>3</b>	<b>Commissioning.....</b>	<b>6</b>
3.1	Required equipment.....	6
3.2	Commissioning tasks .....	7
3.2.1	Loading motor parameters .....	8
3.2.2	Starting field bus.....	9
3.2.3	Selecting operating mode.....	10
3.2.4	Testing measuring system.....	10
3.2.5	Control loop monitoring .....	12
3.2.6	Connecting Control unit IndraDrive to the power supply.....	13
3.2.7	Release of the controller (RF).....	13
3.2.8	Set reference controller .....	13
3.2.9	Set absolute measurement.....	15
3.2.10	Mounting the drive .....	15
3.2.11	Set the parameters for the software controlled limits.....	16
3.2.12	Set the parameters for the position and speed controllers .....	17
3.2.13	Commutation setting (only up to firmware 16V10).....	18
<b>4</b>	<b>Appendices .....</b>	<b>19</b>
4.1	Connection diagram IndraDrive.....	19
4.2	Designation key of files for motors .....	21
4.3	Overview of motor types .....	22

# 1 About this manual

## 1.1 Purpose/validity

This manual is part of the drive control unit IndraDrive and describes the safe and proper start up of the linear drive LDx.

## 1.2 Applicable documents (on CD-ROM)

You can find the following documents on our homepage:

Document	Purpose
Catalog	Technical data and application parameters for the module and information on accessories. The respective latest version is valid
Assembly and operating manuals for linear motor drives	Detailed information about assembly, adjustment and start-up of linear motor drives.
Manual and references for Control unit IndraDrive	Detailed information about assembly, adjustment and repair of the Control unit IndraDrive.
General terms of business	Including notes on the warranty.

Tabelle 1

## 1.3 Symbols in this manual

To give you quick access to information, the following symbols will be used in this manual:





Symbol	Meaning
 <b>DANGER</b>	Dangers for persons. Nonobservance causes death or serious injuries.
 <b>WARNING</b>	Dangers for persons. Nonobservance can cause death or serious injuries.
 <b>CAUTION</b>	Dangers for persons. Nonobservance can cause slight injuries.
 <b>NOTICE</b>	Information on avoiding material damage.
✓	Prerequisite for a handling instruction.
➔	Handling instruction, also measures in a warning or note.
1. 2.	Step-by-step handling instruction. ➔ Observe the order.
< >	Menus and menu items

Tabelle 2

## **2 Basic safety notes**

### **2.1 Intended use**

The module is intended for installation in a machine. The requirements of the applicable guidelines must be observed and complied with.

The module may be used only in the context of its defined application parameters.

Any other use or use exceeding that specified is an infringement of use for intended purpose. The manufacturer bears no liability for damage resulting from such use.

### **2.2 Environmental and operating conditions**

- ➔ The module may be used only in the context of its defined application parameters (see catalog and applicable documents).
- ➔ Make sure that the environment is free from splash water and vapors as well as from abrasion or processing dust. Excepted are modules that are designed especially for contaminated environments.

### **2.3 Controlled production**

The module represents the state of the art and the recognized safety rules at the time of delivery. However, it can present risks if, for example:

- The module is not used in accordance with its intended purpose.
- The module is not installed or maintained properly.
- The EC Machinery Directive, the VDE directives, the safety and accident-prevention regulations valid at the usage site, or the safety and installation notes are not observed.

#### **2.3.1 Protective equipment**

- ➔ Provide protective equipment per EC Machinery Directive.

### 2.3.2 **Constructional changes, attachments, or modifications**

Additional drill holes, threads, or attachments that are not offered as accessories by SCHUNK may be attached only with permission of SCHUNK.

## 2.4 **Personnel qualification**

The assembly, initial commissioning, maintenance, and repair of the Control unit may be performed only by trained specialist personnel.

Every person called upon by the operator to work on the module must have read and understood the complete Assembly and Operating Manual, especially chapter 2 “Basic safety note”. This applies particularly to occasional personnel such as maintenance personnel.

## 2.5 **Safety-conscious working**

- ➔ Avoid any manner of working that may interfere with the function and operational safety of the Control unit.
- ➔ Observe the safety and accident-prevention regulations valid at the usage site.

# 3 **Commissioning**

## 3.1 **Required equipment**

The following equipment/requirements are necessary for commissioning a drive with IndraDrive:

- ✓ a fully installed drive with an IndraDrive drive control unit (for connection schematics, see chapter “4”)
- ✓ PC with network connection
- ✓ IndraWorks operating software (from Version 08Vxx) installed on PC
- ✓ Ethernet (Patch cable) PC connection cable - IndraDrive (order no. 329 962)
- ✓ Commissioning CD with the motor parameters and the files for parameter selection.

## 3.2 Commissioning tasks

### **DANGER**

**Danger to life due to electric shock!**

**Touching live parts can cause death.**

→ Only professional electricians may carry out work on electrical systems and equipment under compliance of the rules for working with electrical systems..

### **NOTICE**

**Damage to the guided slides or guide rail is possible!**

**Activating the “Automatic set up of the control circuit” command can lead to a crash of the guided slide.**

→ Under no circumstances activate the automatic set up of the control circuit for motors.

1. Wire drive control unit IndraDrive to higher order controller in accordance with the connection schematics.  
(siehe Kapitel 4, Seite 19)
2. Create connection between PC and controller.
3. Start IndraWorks on PC.

#### **Note**

Operation of IndraWorks is explained in the help menu of the program.

### 3.2.1 Loading motor parameters

- 1 In the main window of IndraWorks, select <View> → <Project Explorer>. The Project Explorer opens.




Fig. 1 Project Explorer




Fig. 2 Select linear motor type

2. Select <IndraDrive> with right mouse button and then in the context menu <Parameter handling> → <Import>: The dialog box appears:






Fig. 3 Import motor parameters

3. Select file <motor parameter> on the commissioning-DVD.
  4. Select the appropriate motor parameter file name from the description key and the mapping file linear-drive motor.
  5. Select the folder of the linear motor types in the dialog box.
  6. Select desired motor parameter file in the next dialog box and open it.
- The motor parameters are loaded.



Fig. 4 Load motor parameters

### 3.2.2 Starting field bus

1. Configure field bus interface in accordance with IndraDrive manufacturer documentation and control cabinet documentation.
2. Connect and start field bus.
3. Implement and check the wiring for controller enable, stop, reference switch and limit switch, depending on the field bus interface.

### 3.2.3 Selecting operating mode

#### **⚠ WARNING**

##### Risk of injury!

**An improperly set operating mode can lead to undesired drive movement.**

- ➔ Under no circumstances set the operating modes “Torque control” or “Speed control”
- ➔ Activate the drag fault monitoring and configure it sensibly

- ➔ Switch the control unit into the operating mode (phase 4).

In the standard control display on drive control unit IndraDrive<sub>BB</sub> will be displayed.

### 3.2.4 Testing measuring system

1. In the tree view of the project Explorer, select <IndraDrive> ➔ folder <axis>.




Fig. 5 checking status

2. Right click <Type of application> and then select <Diagnostics> from the resulting context menu ➔ Select <Status>..  
The window for the <Status> folder will open.

### Check and activate the pneumatic brake (optional) check and activate

**! NOTICE****Damage to the linear motor axis possible!**

Guide blade carrier and pneumatic holding brake can be damaged by forcible displacement of the carriage.

- ➔ Do not move the guide blade carrier or carriage with force during active holding brake.
- ➔ Use only low-power to examine the function of the pneumatic holding brake of the carriage.

1. Try to move the carriage careful by hand during holding brake.
2. Apply 24-V power supply to the brake valve.  
The pneumatic brake (optional) is activated.

#### Check display and scaling of the measurement system

1. Move the carriage by hand.  
There should be no leaps in the display "position" (see the red mark in Fig. 5 page 6).
2. Apply a Scale (about 10 cm) on the guide blade carriage and move carrier along the scale.
3. Compare the measured travel distance with the display of the actual position.

### 3.2.5 Control loop monitoring




Fig. 6 control loop monitoring

1. In the tree view of the project Explorer, select  
<IndraDrive> → <Motion> → <Axis> → <Control> → <Axis →  
control> → <control loop monitoring>

The dialog box <Control loop monitoring> appears:

#### NOTICE

##### **Damage to the carriage and guide blade carrier is possible!**

A disabled or set too high loop monitoring window can lead to a crash of the carriage.

➔ Set useful control loop monitor parameters.

2. Activate <Speed control loop monitoring> in the option field.
3. Parameterize the position control loop monitoring.

### 3.2.6 Connecting Control unit IndraDrive to the power supply

- ➔ Switch on power at the control switch cabinet (power supply connection 380 V).
- ➔  $\overline{AB}$  appears on the display of the standard operating field of the Control unit IndraDrive which indicates that the Control unit IndraDrive is connected to the power supply

### 3.2.7 Release of the controller (RF)

#### Note

The control release can be linked up by software or hardware depending on the field bus system.

1. Link up with control release (RF).
2. Link up with „Hold“.

On the display of the standard panel at the IndraDrive  $\overline{AF}$  or hold  $\overline{AH}$  appears.

### 3.2.8 Set reference controller

This section is only required if an incremental measuring system is used.

1. In the tree view of the project Explorer, select <IndraDrive> ➔ <Motion> ➔ <Axis> ➔ <Create position data reference> ➔ <Data reference motor encoder>. The dialog box <Data reference motor encoder> appears:




Abb. 7 Measurement motor encoder - incremental

2. Move the guide carriage with Field bus slowly in both directions.
3. Test and parameterize the direction, speed and acceleration.

### 3.2.9 Set absolute measurement

This chapter is only required, if an absolute measuring system is used (TTK 70)

1. In the tree view of the project Explorer, select <IndraDrive> → <motor, brake measuring system> <motor encoder> <assign measurements>




Fig. 8 set absolute measurement

2. Bring the axis in the desired position and click the button < Set absolute measurement >.
3. A desired shifting of the offset can be entered in the box <reference measurement.

#### Note

Perform Parameterization according to the functional description in the documentation of the drive controller Rexroth IndraDrive.

### 3.2.10 Mounting the drive

1. Mount all moving modules (moving mass).
2. Set the end switch
3. Move drive to the intended position.

### 3.2.11 Set the parameters for the software controlled limits

1. In the tree view of the Project Explorer, select <IndraDrive> → <Motion> → <Axis> → <Travel limits>.

The <Travel limits> window will open:




Fig. 9 Travel limits

2. Activate the <Position limit monitor> field
3. Activate the <Travel limit switch> field
4. Configure the travel limit values in the dialog box



### 3.2.12 Set the parameters for the position and speed controllers

1. In the tree view of the Project Explorer, select <IndraDrive> → <Motion> → <Axis> → <Axis control> → Select <Axis control settings>

The <Axis control settings> window will open




Fig. 10 Axis control settings

2. Make the fine adjustments for the position and speed controllers.

#### Note

Set the parameters as specified in the functional description in the documentation for the Rexroth IndraDrive (chapter <Drive controller>, section <axis control (closed loop mode)>).

### 3.2.13 Commutation setting (only up to firmware 16V10)

1. In the tree view of the project Explorer, select <IndraDrive> → <Application type> → <Drive control> → <Motor control> → <Commutation setting>. The <Commutation setting> dialog window appears:




Fig. 11 Commutation settings

Up to firmware 16V10, a manual modification needs to be made upon initial commutation of the drive. During its initial commutation, the drive searches independently for a voltage vector (amplitude in the test signal (see Fig. 11). In certain cases, this value is not enough to drive the motor to saturation. Therefore the value needs to be increased manually. For example, if the automatically calculated value is 68V, simply increase it by **40** to 108V. Every value that the controller calculates should be increased by **40**.

#### Note

With firmware version 16V12 and higher, manual intervention in the parameter settings is no longer necessary. The process of commutation finding was improved in these versions.






Fig. 12 Connection diagram IndraDrive

## 4.2 Designation key of files for motors

AAA	- B B	- CCCC	- DD	- E	- FFF	- GGG	- HHH	- III
<b>Profiltyp</b>								
H- Profil	LDH							
K- Profil	LDK							
FU- Profil	LDF							
N- Profil	LDN							
M- Profil	LDM							
T- Profil	LDT							
P- Profil	LDP							
H- Profil (CFK)	LCH							
K- Profil (CFK)	LCK							
FU- Profil (CFK)	LCF							
N- Profil (CFK)	LCN							
M- Profil (CFK)	LCM							
T- Profil (CFK)	LCT							
P- Profil (CFK)	LCP							
<b>Bauart</b>								
Einzelmotor / Single Motor	E							
Doppelmotor / double motor	D							
Unterstützes Profil / U Profil	U							
<b>Schlitten</b>								
Standard	S							
Lang / long	L							
Groß / large	G							
<b>Baugröße</b>								
<b>Wicklungskennung</b>								
Standardwicklung	01							
<b>Gebertyp</b>								
LS100	Sin/Cos, 1 Vss, 1 mm Periode (SIKO)	1						
LE100	Sin/Cos, !Vss Periode (SIKO) mit Referenzmarke	1						
LIDA489	Sin/Cos, 1 Vss, 20 µm Periode (Heidenhain)	2						
LIA22	Sin/Cos, 1 Vss, 20 µm Periode (NUMERIK)	2						
TTK70	Sin/Cos, 1Vss Hiperface absolut (Sick Stegmann)	3						
RS40,5/25/2048	Sin/Cos, 1 Vss, 2048 Perioden/Umdr. (NUMERIK)	4						
RS30/16/1000	Sin/Cos, 1 Vss, 1000 Perioden/Umdr. (NUMERIK)	5						
Reserve		6						
<b>Reglertyp</b>								
Indradrive	IDR							
Indradrive CS	IDC							
<b>Option 1</b>								
Encoder EnDat / 1Vss/TTL	EN2							
Encoder IndraDyn / Hyperface	ENS							
Encoder 1Vss	EC							
<b>Option 2</b>								
Encoder EnDat / 1Vss/TTL	EN2							
<b>Version</b>								
Auslieferungsstand	Vxx							

Fig. 13 Designation key of files for motors

### 4.3 Overview of motor types

Motorbez.	Achsnname	Dateien	Kurzname	Länge	Breite	Höhe	Wicklung	Gebertyp	Wellentyp	Regler	Steuerteil	Option1	Option2	Version	Suffix	
			AAAAAA	BBB	CCC	DDD	EE	F	G	HHH	III	JJJ	KKK	LLL		
MGH-ES-0050	LDH-ES-0050 LDH-US-0050	Achsenbez.	LDH005	- 150	- 058	- 037	- 01	- X	- X	-						
		Motorparameter	LDH005	- 150	- 058	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDH005	- 150	- 058	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDH005	- 150	- 058	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGK-ES-0100	LDK-ES-0100 LDK-US-0100	Achsenbez.	LDK010	- 150	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDK010	- 150	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDK010	- 150	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDK010	- 150	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGK-EL-0200	LDK-EL-0200 LDK-UL-0200	Achsenbez.	LDK020	- 250	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDK020	- 250	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDK020	- 250	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDK020	- 250	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGF-US-0100	LDF-US-0100	Achsenbez.	LDF010	- 150	- 100	- 037	- 01	- X	- X	-						
		Motorparameter	LDF010	- 150	- 100	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDF010	- 150	- 100	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDF010	- 150	- 100	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGF-UL-0200	LDF-UL-0200	Achsenbez.	LDF020	- 250	- 100	- 037	- 01	- X	- X	-						
		Motorparameter	LDF020	- 250	- 100	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDF020	- 250	- 100	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDF020	- 250	- 100	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGN-ES-0100	LDN-ES-0100 LDN-US-0100	Achsenbez.	LDN010	- 150	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDN010	- 150	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDN010	- 150	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDN010	- 150	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGN-EL-0100	LDN-EL-0100	Achsenbez.	LDN010	- 150	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDN010	- 150	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDN010	- 150	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDN010	- 150	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGN-DS-0200	LDN-DS-0200	Achsenbez.	LDN020	- 150	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDN020	- 150	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDN020	- 150	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDN020	- 150	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGN-EL-0200	LDN-EL-0200 LDN-UG-0300 LDP-EL-0200	Achsenbez.	LDN020	- 250	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDN020	- 250	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDN020	- 250	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDN020	- 250	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
MGN-EG-0300	LDN-EG-0300 LDN-UG-0300 LDP-EG-0300	Achsenbez.	LDN030	- 350	- 085	- 037	- 01	- X	- X	-						
		Motorparameter	LDN030	- 350	- 085	- 037	- 01	- 1	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
			LDN030	- 350	- 085	- 037	- 01	- 2	- X	- IDC	- NNN	- EC	- NN	- V01	. par	
		Motordaten	LDN030	- 350	- 085	- 037	- 01	- 3	- X	- IDC	- NNN	- EC	- NN	- V01	. par	

Fig. 14 Assignment of the motors to the drives and files (page 1 of 3)

Motorbez.	Achsnname	Dateien	Kurznamen																								
			Kurzname	Länge	Breite	Höhe	Wicklung	Gebertyp	Weilertyp	Regler	Steuerteil	Option1	Option2	Version	Suffix												
			AAAAA	BBB	CCC	DDD	EE	F	G	HHH	III	JJJ	KKK	LLL													
2x MGN-EL-0200	LDM-DL-0400	Achsenbez.	LDM010	-	150	-	170	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDM010	-	150	-	170	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM010	-	150	-	170	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM010	-	150	-	170	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDM010	-	150	-	170	-	037	-	01	-												MOT	-	V01	-	xls
2x MGN-EG-0300	LDM-DG-0600	Achsenbez.	LDM060	-	350	-	085	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDM060	-	350	-	085	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM060	-	350	-	085	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM060	-	350	-	085	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDM060	-	350	-	085	-	037	-	01	-												MOT	-	V01	-	xls
MGM-ES-0100	LDM-ES-0100	Achsenbez.	LDM020	-	250	-	170	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDM020	-	250	-	170	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM020	-	250	-	170	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM020	-	250	-	170	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDM020	-	250	-	170	-	037	-	01	-												MOT	-	V01	-	xls
MGM-ES-0200	LDM-ES-0200	Achsenbez.	LDM020	-	250	-	170	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDM020	-	250	-	170	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM020	-	250	-	170	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM020	-	250	-	170	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDM020	-	250	-	170	-	037	-	01	-												MOT	-	V01	-	xls
MGM-EL-0200	LDM-EL-0200	Achsenbez.	LDM020	-	250	-	170	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDM020	-	250	-	170	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM020	-	250	-	170	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM020	-	250	-	170	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDM020	-	250	-	170	-	037	-	01	-												MOT	-	V01	-	xls
MGM-EL-0400	LDM-EL-0400	Achsenbez.	LDM040	-	250	-	170	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDM040	-	250	-	170	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM040	-	250	-	170	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDM040	-	250	-	170	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDM040	-	250	-	170	-	037	-	01	-												MOT	-	V01	-	xls
MGT-ES-0100	LDT-ES-0100	Achsenbez.	LDT010	-	150	-	250	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDT010	-	150	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT010	-	150	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT010	-	150	-	250	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDT010	-	150	-	250	-	037	-	01	-												MOT	-	V01	-	xls
MGT-ES-0200	LDT-ES-0200	Achsenbez.	LDT020	-	250	-	250	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDT020	-	250	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT020	-	250	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT020	-	250	-	250	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDT020	-	250	-	250	-	037	-	01	-												MOT	-	V01	-	xls
MGT-ES-0300	LDT-ES-0300	Achsenbez.	LDT030	-	350	-	250	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDT030	-	350	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT030	-	350	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT030	-	350	-	250	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDT030	-	350	-	250	-	037	-	01	-												MOT	-	V01	-	xls
MGT-EL-0200	LDT-EL-0200	Achsenbez.	LDT020	-	250	-	250	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDT020	-	250	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT020	-	250	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT020	-	250	-	250	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDT020	-	250	-	250	-	037	-	01	-												MOT	-	V01	-	xls
MGT-EL-0400	LDT-EL-0400	Achsenbez.	LDT040	-	250	-	250	-	037	-	01	-	X	-	X	-											
		Motorparameter	LDT040	-	250	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT040	-	250	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
			LDT040	-	250	-	250	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par
	Motordaten	LDT040	-	250	-	250	-	037	-	01	-												MOT	-	V01	-	xls

Fig. 15 Assignment of the motors to the drives and files (page 2 of 3)

Motorbez.	Achsnname	Dateien	Kurznamen																									
			Kurzname	Länge	Breite	Höhe	Wicklung	Gebertyp	Wellentyp	Regler	Steuerteil	Option1	Option2	Version	Suffix													
			AAAAAA	-	BBB	-	CCC	-	DDD	-	EE	-	F	-	G	-	HHH	-	III	-	JJJ	-	KKK	-	LLL	-		
MGT-EL-0600	LDT-EL-0600 LDT-UL-0600	Achsenbez.	LDT060	-	350	-	250	-	037	-	01	-	X	-	X	-												
		Motorparameter	LDT060	-	350	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
			LDT060	-	350	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
		Motordaten	LDT060	-	350	-	250	-	037	-	01	-												MOT	-	V01	-	xls
2x MGT-EL-0400	LDT-DL-0800	Achsenbez.	LDT080	-	250	-	250	-	037	-	01	-	X	-	X	-												
		Motorparameter	LDT080	-	250	-	250	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
			LDT080	-	250	-	250	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
			LDT080	-	250	-	250	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
Motordaten	LDT080	-	250	-	250	-	037	-	01	-												MOT	-	V01	-	xls		
2x MGT-EL-0600	LDT-DL-1200	Achsenbez.	LDT120	-	250	-	170	-	037	-	01	-	X	-	X	-												
		Motorparameter	LDT120	-	250	-	170	-	037	-	01	-	1	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
			LDT120	-	250	-	170	-	037	-	01	-	2	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
			LDT120	-	250	-	170	-	037	-	01	-	3	-	X	-	IDC	-	NNN	-	EC	-	NN	-	V01	-	par	
Motordaten	LDT120	-	250	-	170	-	037	-	01	-												MOT	-	V01	-	xls		

Fig. 16 Assignment of the motors to the drives and files (page 3 of 3)